



Vijeo Citect

Quick-Start Tutorial Part 2

Advanced Configuration Topics

This tutorial will guide you to build and run a project with Vijeo Citect V7.30.

Important Information

People responsible for the application, implementation and use of this document must make sure that all necessary design considerations have been taken into account and that all laws, safety and performance requirements, regulations, codes, and applicable standards have been obeyed to their full extent.

Schneider Electric provides the resources specified in this document. These resources can be used to minimize engineering efforts, but the use, integration, configuration, and validation of the system is the user's sole responsibility. Said user must ensure the safety of the system as a whole, including the resources provided by Schneider Electric through procedures that the user deems appropriate.

Notice

This document is not comprehensive for any systems and does not absolve users of their duty to uphold the safety requirements for the equipment used in their systems, or compliance with both national or international safety laws and regulations.

This document does not replace any specific product documentation.

The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

Failure to follow these instructions will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

Failure to follow these instructions can result in death, serious injury or equipment damage.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

Failure to follow these instructions can result in injury or equipment damage.

NOTICE

NOTICE is used to address practices not related to physical injury.

Failure to follow these instructions can result in equipment damage.

Note: Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, operation and installation of electrical equipment, and has received safety training to recognize and avoid the hazards involved.

Before You Begin

Vijeo Citect is used to retrieve, collate and publish data from Supervisory Control and Data Acquisition (SCADA) systems to manage and monitor industrial systems and processes. Due to Vijeo Citect's central role in managing data within control systems and processes, you must appropriately design, commission, and test your Vijeo Citect project before implementing it in an operational setting.

WARNING

UNINTENDED EQUIPMENT OPERATION

Do not use Vijeo Citect or other SCADA software as a replacement for PLC-based control programs. SCADA software is not designed for direct, high-speed system control.

Failure to follow these instructions can result in death, serious injury or equipment damage.

WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines.¹
- Each implementation of a control system created using Vijeo Citect must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury or equipment damage.

¹ For additional information, refer to NEMA ICS 1.1 (latest edition) "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control", and to NEMA ICS 7.1 (latest edition) "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

CAUTION

EQUIPMENT INCOMPATIBILITY OR INOPERABLE EQUIPMENT

Read and thoroughly understand all hardware and software documentation before attempting any component substitutions.

Failure to follow these instructions can result in injury or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions and government regulations etc. In some applications more than one processor may be required when backup redundancy is needed.

Only the user can be aware of all the conditions and factors present during setup, operation and maintenance of the solution. Therefore only the user can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, the user should refer to the applicable local and national standards and regulations. The National Safety Council's Accident Prevention Manual also provides much useful information.

Ensure that appropriate safeties and mechanical/electrical interlocks protection have been installed and are operational before placing the equipment into service. All mechanical/electrical interlocks and safeties protection must be coordinated with the related automation equipment and software programming.

Note: Coordination of safeties and mechanical/electrical interlocks protection is outside the scope of this document.

Start Up and Test

Following installation but before using electrical control and automation equipment for regular operation, the system should be given a start up test by qualified personnel to verify the correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

WARNING

EQUIPMENT OPERATION HAZARD

- Follow all start up tests as recommended in the equipment documentation.
- Store all equipment documentation for future reference.
- Software testing must be done in both simulated and real environments.

Failure to follow these instructions can result in death, serious injury or equipment damage.

Verify that the completed system is free from all short circuits and grounds, except those grounds installed according to local regulations (according to the National Electrical Code in the USA, for example). If high-potential voltage testing is necessary, follow recommendations in the equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment
- Close the equipment enclosure door
- Remove ground from incoming power lines
- Perform all start-up tests recommended by the manufacturer

Operation and Adjustments

The following precautions are from NEMA Standards Publication ICS 7.1-1995 (English version prevails):

Regardless of the care exercised in the design and manufacture of equipment or in the selection and rating of components; there are hazards that can be encountered if such equipment is improperly operated.

It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.

Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

WARNING

UNEXPECTED EQUIPMENT OPERATION

- Only use software tools approved by Schneider Electric for use with this equipment.
- Update your application program every time you change the physical hardware configuration.

Failure to follow these instructions can result in death, serious injury or equipment damage.

Intention

This document is intended to provide a quick introduction to Vijeo Citect. It is not intended to replace any specific product documentation, nor any of your own design documentation. On the contrary, it offers information additional to the product documentation on installation, configuration and implementing the system.

The application described in this document is not a specific product in the normal commercial sense. It describes an example of how Schneider Electric and third-party components may be integrated to fulfill an industrial application.

A detailed functional description or the specifications for a specific user application is not part of this document. Nevertheless, the document outlines some typical applications where the system might be implemented.

The application described in this document is for illustration purpose. Your specific application requirements may be different and will require additional and/or different components. In this case, you will have to adapt the information provided in this document to your particular needs. To do so, you will need to consult the specific product documentation of the components that you are substituting in this application. Pay particular attention in conforming to any safety information, different electrical requirements and normative standards that would apply to your adaptation.

It should be noted that there are some major components in the application described in this document that cannot be substituted without completely invalidating the architecture, descriptions, instructions, wiring diagrams and compatibility between the various software and hardware components specified herein. You must be aware of the consequences of component substitution in the architecture described in this document as substitutions may impair the compatibility and interoperability of software and hardware.

CAUTION

EQUIPMENT INCOMPATIBILITY OR INOPERABLE EQUIPMENT

Read and thoroughly understand all hardware and software documentation before attempting any component substitutions.

Failure to follow these instructions can result in injury or equipment damage.

Table of Contents

1.	Introduction	10
1.1.	<i>Purpose</i>	10
2.	Security Validation	11
3.	Equipment Import	13
4.	Using Super Genies	18
4.1.	<i>Creating a Super Genie</i>	18
5.	Using Genies	27
5.1.	<i>Creating a Genie</i>	27
5.2.	<i>Using Genies on Graphics Pages</i>	32
6.	Tag Data Quality	36
6.1.	<i>Tag Override</i>	36
6.2.	<i>Control Inhibit</i>	42



1. Introduction

Welcome, and thank you for purchasing Vijeo Citect. This tutorial is an extension of the Vijeo Citect Quick Start Tutorial Guide Part 1, and builds on the concepts and project configuration developed in that guide. If you have not completed the Quickstart Tutorial Part 1, please do so now before commencing work with this extension.

1.1. Purpose

This tutorial will demonstrate some of the advanced sections of the product:

- Security Validation related to electronic signatures and multi-user validation
- Super-Genies for efficient project configuration and maintenance
- Genies for efficient project configuration and maintenance
- Tag Data Quality and Tag Management
- Equipment Import process for bulk creation of project objects

1.1.1. Disclaimer

Schneider Electric makes no representations or warranties with respect to the contents or use of this manual and, to the extent permitted by law, expressly limits its liability for breach of any warranty that may be implied to the replacement of this manual with another. Schneider Electric assumes no responsibility for any errors that may be in this document and reserves the right to revise this document at any time without incurring an obligation to notify any person of the revision.

Copyright © October 2012, Schneider Electric. All rights reserved. No part of this document may be reproduced, photocopied, or transmitted in any form or by any means (electronic or mechanical), for any purpose, without the express written permission of Schneider Electric.

1.1.2. Trademarks

Vijeo Citect, Vijeo Citect Lite, Vijeo Historian, Vijeo Designer, Vijeo Look, and AMPLA are registered trademarks of Schneider Electric.

Windows is a trademark of Microsoft Corporation. All other brand or product names may be trademarks of their respective holders.




2. Security Validation

Vijeo Citect contains security functions to make it easier for companies to implement electronic signatures and multi-user validation. This exercise will modify the Pump 1 manual button to require signature validation before changing the mode to Manual (setting the Pump_1_Mode value to 1).

Switch to the Graphics Builder. Open your MyPage graphics display, and double-click on the Manual button to access its animation properties. Click on the Input tab, and modify the command to:


```
MultiSignatureTagWrite("Pump_1_Mode", "1", "", "kernel", "", "", "")
```



Save your page. Switch to the Vijeo Citect Editor and compile your project. Run your project.


Once the project is running, open MyPage, and click on the Manual button. Instead of immediately changing the pump's mode to manual, Vijeo Citect will display an electronic signature verification form.

Click on the Verify button, then enter the password for the kernel user you created earlier and click OK.





An approval dialog is displayed.



Click Ok. The pump mode will now be changed to Manual. Further information on electronic signatures and user validation can be found in the online help.



3. Equipment Import

One of the big benefits to using Equipment definitions in your project is that you can bind the Equipment Type to a defined object model in an XML file. This means that when you add equipment of this type, a number of items in your Vijeo Citect project are configured automatically for you. A simple example is to automatically create tags, alarms and trends for each piece of identical equipment.

In the Tutorial project, you have a simple pump, with mode, run and speed controls. In the real world, equipment typically comprises ten or twenty signals depending on its complexity. Most sites try to standardize on their electrical infrastructure so that MCC circuits and valve blocks are consistent for different types of equipment. This lends itself very well to equipment templates.

To demonstrate this, you will expand your pump definition to include the following features:


Item type	Name	Description
Variable	<equipment>_Run	Run control (stopped when off)
Variable	<equipment>_Mode	Manual mode (auto when off)
Variable	<equipment>_Fault	General fault for alarming purposes
Variable	<equipment>_CB	Circuit Breaker closed (open when off)
Variable	<equipment>_Speed	Speed control
Variable	<equipment>_Temperature	Bearing temperature
Digital Alarm	<equipment>_Fault	Pump general fault
Digital Alarm	<equipment>_CB	Pump circuit breaker open
Analog Alarm	<equipment>_Speed	Alarm when running too slow or too fast
Analog Alarm	<equipment>_Temperature	Alarm only when temperatures are too high

As part of the Tutorial download, you will have downloaded a file called “EquipDef_Pump.xml”. Copy this into your project folder, normally:

```
C:\ProgramData\Schneider Electric\Vijeo Citect 7.30\User\Tutorial
```

This file contains the equipment definition for your upgraded pump. Next, you will delete your existing variables, alarms and trends from the project so that the equipment import process can take control of these items.


Open the Variable Tags form in the Project Editor, and delete all of the current records in your project.



When you have finished, repeat for your Digital Alarms, Analog Alarms and Trend definitions.




Vijeo Citect allows you to have a mix of items managed by the Equipment Import process as well as manually edited items. All of your tags will be managed by the Equipment Import process so you are deleting all of your tags. If you manually created a tag for your tank level earlier, you can leave that tag and associated alarms and trends alone.






When you are finished, select Pack from the File menu in the Citect Editor. This will permanently delete the records you have just marked for deletion, and reindex your configuration database.

Open the Equipment Type definition form in the Project Editor. Update the Pump type to include a template definition of EquipDef_Pump.xml. When you are finished, click Replace.



Open the Equipment definitions in the Project Editor. If the lower section of the form is not displayed, click F2 to extend the form properties.



The EquipDef_Pump.xml template uses the first six custom fields of the equipment definition to define the analogue alarm limits for the Speed alarm as follows:

- Custom Field 1 High High limit
- Custom Field 2 High limit
- Custom Field 3 Low limit
- Custom Field 4 Low Low limit
- Custom Field 5 Deadband
- Custom Field 6 Alarm Category

Update the Pump_1 equipment definition as shown above then click Replace.

Repeat for Pump_2, and create a new equipment item, Pump_3. Remember to hit Replace for Pump_2 and Add for Pump_3.



Equipment [Tutorial]

Name: Pump_2, Type: Pump, Cluster Name: Cluster1, Tag Prefix: Pump_2, I/O Device: IODev, Page: Help, Location: , Area: , Comment: Water Removal Pump

Default State: , Scheduled: , Composite:

Parameters:

Custom	Value
Custom 1	95
Custom 2	90
Custom 3	15
Custom 4	10
Custom 5	2
Custom 6	1
Custom 7	
Custom 8	

Record : 2, Linked: No

Equipment [Tutorial]

Name: Pump_3, Type: Pump, Cluster Name: Cluster1, Tag Prefix: Pump_3, I/O Device: IODev, Page: Help, Location: , Area: , Comment: Dosing Pump


Default State: , Scheduled: , Composite:

Parameters:

Custom	Value
Custom 1	95
Custom 2	90
Custom 3	15
Custom 4	10
Custom 5	2
Custom 6	1
Custom 7	
Custom 8	

Record : 3, Linked: No

When you are finished, close the forms and select Update Equipment from the Tools menu in the Project Editor.



The system will process all of the defined equipment based on the template files they are linked to. To validate this, re-open your Variable Tags form and scroll through the defined tags. You should have 18 tags now, six for each of the three pumps.

Variable Tags [Tutorial]

Equipment: Pump_3, Item Name: Temperature, Cluster Name: Cluster1, Comment: Dosing Pump temperature (0 - 320 deg C)

Tag Name: Pump_3_Temperature, I/O Device: IODev, Address: Pump_3.temperature, Data Type: REAL, Eng Zero Scale: 0, Eng Full Scale: 320

Record : 18, Deleted: , Linked: Yes

Similarly, you should have 9 digital alarms, 6 analogue alarms and 6 trend definitions. All of these variables are immediately available for you to use in your graphics pages, and the alarms and trends are immediately available to use in your runtime project.



Re-compile and run your project and verify that your project continues to run as expected. See if you can add two more pumps onto your graphics page and control them in a similar way to the first pump.

TIP Equipment Templates can be very powerful. You can create your own XML templates to create and manage most aspects of the Vijeo Citect Editor forms in relation to your equipment. They can be extended to use arrays of parameters from both the custom fields and the parameters field in the equipment definition. For more details on how to create your own templates, refer to the online help.


4. Using Super Genies

Super Genies are pages which can dynamically switch between different tag groups at runtime. You will create a page which hosts the manual, auto and run buttons for Pump1, and then reuse the page for pumps 2 and 3. When your project grows to include many instances of similar equipment, sequences or other items, Super Genies can save you a lot of development time.

Super Genies are configured just like pages, but placeholders are inserted instead of direct tag references. To use Super Genies, you must either link them to Genies (see the next chapter), or call them from Cicode. For more information on Super Genies, refer to the online help.

4.1. Creating a Super Genie

Create a new graphics item, and select Super Genie when prompted.





A new empty page will appear. The dotted lines identify the default page size for the popup.



Firstly, you will add fixed title to your Super Genie page.


Click on the Text object on the Toolbox.

Type "PUMP" and click to place the text on the page. Modify the font, color, size and 3D shadowing to suit your preferences, then click OK.




Adjust the position of the title by placing it on top of the page, centered. Don't worry about the animation numbers showing on the screen. Just place your text on top of them.

Click on the Toolbar and select the text tool once again. Type in "Title" and click to place it on the screen. Modify the font, color, size and 3D settings to suit your preferences. Modify the alignment to be "Centre".



Before you close the form, click on the Display Value tab on the far right of the form. Change the display type to String, and type in a string expression of ?Title?. The question marks identify this text as placeholder text, which will be replaced by a dynamic value at runtime, depending on what data is passed into the page. In this case, you will pass in the name of the pump (Pump_1, Pump_2 or Pump_3) and display it here.




Click OK to close the form, and position this new text in the centre of the page, just below your previous text.




Select the Straight Line tool from the Toolbox. Click on the left side of your page slightly below the Title text and holding the mouse draw a straight line to the right side of your page. Using the grid will help keep your lines straight.

Experiment with colors and shading to get the effect you desire, then click OK.




Now, you will replicate the same three controls for the pump on your Super Genie page. Use File



Open to open your previous graphics page with the pump and tanks on it. Holding the Ctrl key down, click on the three control buttons and their corresponding lights, then click Ctrl-C to copy them to the clipboard.


Switch back to your Super Genie (Ctrl-F6), and paste these items onto your page using Ctrl-V.




You will now update each of these items to use Super Genie references instead of directly accessing tags.

Double click on the Manual button to access its properties. Modify the Input command to:

Mode? = 1




Click OK to close the form. Similarly, modify the Auto button command to: **?Mode?=0**






Access the On / Off button and modify its command to: **Toggle (?Run?)**




And its Disabled Access expression to: **?Mode? = 0**



Notice that you are simply replacing the tag names in the original buttons with parameter names. Once you pass a tag name into the page as one of these parameters, the tag name will be used to acquire and write data instead of the placeholder.

Double click the light next to the Manual button to access its properties. Modify the ON symbol expression to: **?Mode? = 1**




Repeat this process for the Auto light: **?Mode? = 0**


And the On / Off light: **?Run? = 1**

The Super Genie controls and lights configuration is complete. You just require one more button on your page to allow us to close the Super Genie when you have finished using it. Using the Toolbox to add a new button to your form.




Draw the button at the bottom of the form. In the Appearance tab, select the button type as Symbol instead of text. Click Set to browse the symbol libraries for an appropriate image. Select the clos2 icon from the icons library.






Change to the Input tab, and type Winfree() in the Up command expression. This will tell the popup window to close when the button is clicked. Click OK when you are finished.




Your Super Genie should look like this.



So far you haven't defined the tag relationships (called associations) the Super Genie page will use to relate tags to the parameters names you have specified. However, you have used three place holders while designing the graphical layout of your page: ?Mode?, ?Run? and ?Title?. You will now formalize these parameters in preparation of linking the Super Genie to a Genie.





Right-click at an empty location on the page and choose Page Properties from the menu (or select Properties from the File menu).



Select the Associations tab from the top menu and click Add.

Select “Mode” from the pull-down list in the Name column, then type in a meaningful description.

Repeat this for “Run” and “Title”, then click OK to close the form.




Note that when you declare page associations for a Super Genie in the page properties, you do not place the name of the association between question marks. Also notice that the In Use cell next to an association name will automatically indicate “Yes”, if you have referred to that association anywhere on your page.




Once you declared those three associations, make sure that the In Use cell next to each one of them reads Yes. If an association you added is not in use, it means you have not successfully referred to that tag when creating your graphical objects. Follow the previous steps once again and make sure you have typed in the correct expressions.


You have created your first Super Genie. Click the save icon. Genies and Super Genies need to be saved in libraries. If this the first time you are creating a Genie or a Super Genie, you will not be able to do so unless you also create a library. Ensure that the tutorial project is selected, then click on the New button.



On the popup page type in myequipment and click OK. This will create a new library file in your project called myequipment. This file can contain many Super Genies.



Myequipment will now be listed under the library box. Make sure this new library is selected, then give your Super Genie the name “!pump” and click OK to save. An update warning message will appear and click OK.



→ Placing an exclamation mark in front of a page name marks it as a system file, and it is not listed on automatic menus and other locations.



5. Using Genies



You have created your first Super Genie, however it is not very useful yet as your project does not ask it to display, and nor does it pass any tag names to the association parameters. You now need to create a Genie and attach it to the Super Genie.

Generally, you use Genies to create generic equipment or animated graphical symbols which you can reuse many times on your pages. By doing so, you can create a single library object for a specific purpose with known properties and reuse it within your project many times without creating a new object each time. A Genie is similar to a Symbol, but it can store animation information as well as the symbol.

When you use a Genie on a page, that instance is linked with the Genie in the library so that any changes you make after you have used a Genie are automatically populated out across all instances on all pages in your project. This makes modification and maintenance of your project much easier.

5.1. Creating a Genie

In Graphics Builder, create a new item, and select Genie when prompted.




Select, copy and paste your Pump symbol from your graphics page into your new Genie.

Drag the Genie anchor point across to the bottom left of your pump symbol. Remember to turn your Grid off to get pixel accurate position.



Double click the symbol to access its animation properties. Modify the On Symbol expression to:

%Run% = 1



Click on the Input tab from the horizontal menu above. You will add a click command that opens the Super Genie popup.

On two lines, type in:


```
AssMetadata(-2, -2);  
WinNewAt("!pump", 100, 200, 877, "Cluster1");
```

The **AssMetadata** function will perform the required Super Genie associations using the tags or expressions you define when you use your Genie object on a page. The first parameter (-2) specifies that the next window or page displayed will receive the tag associations. The second parameter (-2) specifies that the associations will come from the Genie being clicked.


The **WinNewAt** function displays a new window. First parameter defines the name of the page - in this case, a Super Genie – you want to display. Next two parameters are the X and Y coordinates, respectively, where the window or page will be displayed on the screen. The parameter that follows the X and Y coordinate values is used to determine the window behavior properties (e.g. resize, movement, etc). Refer to the online help to see different window options to be used with the WinNewAt function. The last parameter is the (optional) cluster name.

TIP The mode parameter is the sum of values for individual parameters. Instead of putting the summated value in their expression, many users list out the values explicitly so that it is easier to reference which parameters are being used. For example:

```
WinNewAt("!pump", 100, 200, 1+4+8+32+64+256+512, "MyCluster");
```




Next, select the Metadata tab from the top menu. Click Add and type in “Mode”. Inside the Value cell, type in “%Mode%”. Repeat this for “Run” and “Title”. Note that for Genie placeholders you use % instead of the ? used on Super Genies.




Click OK when you are finished.

Now you will attach the Super Genie you created in the previous exercise. Attaching a Super Genie allows the page to be referenced in your project when the associated Genie is used from the library. Associations to defined tag relationships can also be used on any page in your project.


Select Attach Super Genie from the Edit menu.




On the Attach Super Genie popup screen, you will see that the Genie has no Super Genie attached to it.



Click on the Add Button. Scroll down and select your library by clicking on it, then select your Super Genie and click OK.






You should now see myequipment.!equipment on the list of attached Super Genies. Note that you can attach more than one Super Genie to a Genie object for additional functionality if you desire.

Click OK.

You have successfully created your first Genie and attached the Super Genie page to it. Now, every time you click on the Genie object, the Super Genie page will popup and all the metadata you link to your Genie object will be passed to Super Genie page as associations.

Save your Genie. You can save your Genie into the same library as your Super Genie. Make sure that your myequipment library is selected, and type in genie_pump as your Genie's name, then click OK.



Close your Genie.

Now you have created your genie object and linked it with your Super Genie page, you will take a look at how to use these objects on the page you have previously designed.

TIP Genies can be used on their own without a Super Genie. They still add a lot of value to your project by providing templates for animated symbols, but add even more value when linked to Super Genies.



5.2. Using Genies on Graphics Pages

You will now place the genie object into your MyPage screen. Inside the Graphics Builder, if you don't already have your MyPage screen open it now.




Select the genie icon from the Toolbar.

Scroll down and select myequipment library from the Library list. You should see the genie_pump object on the left hand side. Select it and click OK to add it into your page.

You will be presented with a popup window which prompts you to enter the Genie tags to be used for each of the three parameters used on the Genie. On this window, you should see all the metadata fields you have declared when creating the genie object. You will now enter the desired variable tag names in the empty fields.


To link the variable tag Pump_1_Run to the run Metadata, simply type in the tag name inside the field. Link your Pump_1_Mode tag to the Mode metadata of your genie object.




For the Title metadata, type in the static text 'Pump 1' inside single quotes. Genie associations don't need to be tags, they can be text string or numerical replacements as well, but they must have single quotes around them to allow Vijeo Citect to recognize them as such.

Notice that Title metadata is linked with a constant string expression 'Pump 1'. This is because you do not need to use a variable tag for the title.

If you do not place an expression inside single quotes when linking your metadata, Vijeo Citect will look for a tag with the specified name and if no tags are can be found, you will not be able to see the association on your Supergenie page at runtime. More importantly, if you forget to place your string expression inside single quotes and it happens to be the name of an already declared tag, you will see the value of the tag instead. Your page should now look like this:




At the moment, you have two pumps on your page. One is the genie object and the other is the basic pump symbol you initially created. You no longer need the original pump, so click on it and press delete from your keyboard. Move the new Genie Pump to its place to replace it.



Save your project by clicking the save icon and then click on compile button and run your project.

You will notice when you turn the Pump On and Off from the menu on the bottom right corner, the Genie based pump will change its color just like the original. Now you will see how to make use of the Super Genie popup. You will notice that when you hover your mouse over pump, it will be surrounded by white borders. This indicates that you can click on the object.


Click on the Pump now.




Your !equipment Super Genie page will appear. You should now be able to control the status of Pump 1 directly from the popup window. Click on the On/Off button to toggle between its run modes. You can also press the Auto or Manual button and the status indicators on MyPage will update instantly to represent its new state.

Once you have finished testing your Super Genie page, click the Close button.

You will now demonstrate how quickly you can expand your project once you have the building blocks of Equipment Import, Genies and Super Genies in place.




Return to the Graphics Editor and open you graphics page again. Copy your Genie Pump and place it in two new locations on your page. Double click each of the new pumps and edit their parameters to suit pumps 2 and 3.






Save and close your graphics page.

Select Update Pages from the Tools menu.



Confirm that you want to continue, wait for the process to complete, then re-compile and run your project. You should now be able to access all three pumps and their related popups.



Using Equipment Import, Genies and Super Genies, you can rapidly scale out your project and also control the quality and consistency of your project.



6. Tag Data Quality

Tags have additional properties and methods that you can access for your tags above and beyond their actual values. These include quality flags, quality timestamps, and override functions. For this exercise you will focus on the Tag Override feature.

6.1. Tag Override

Tag Override allows you to set your tag's value to a different value than it is receiving from the field devices. This is useful if a field transmitter has failed, for example.

To illustrate how to use tag override feature, you will define a new variable tag called Tank_1_Level. Open your Project Editor and open the variable tag editor.


Create a new tag for Tank_1_Level as shown below.

Equipment		Cluster Name	Cluster 1
Item Name			
Comment	Tank_1_Level		
Tag name	Tank_1_Level	I/O Device	IODev
Address	Tank_1.Level	Data Type	REAL
Raw Zero Scale	0	Raw Full Scale	32767
Eng Zero Scale	0	Eng Full Scale	100
Eng Units	%	###.# EU	###.# EU
Deadband	0.25	True	True


Switch to the Graphics Builder and open your graphics page. Select the Pump 1 Speed indicator and slide controller, then copy and paste these items to the left of the source tank. You will use



the bar graph to show the level in the tank, as if it were being measured by a field transmitter, and you will use the slider to simulate that field transmitter.



Double click the bar graph to access its properties. Change the Level Fill expression to use the new Tank_1_Level variable tag.






Click OK when you are finished.



Because it is referencing the entire variable tag object, this bar graph will show the value for the currently active mode of the tag. If you switch to Override Mode, it will show the override value, if you switch to Normal Mode, it will show the real value. If instead, you had specified a specific tag data quality, then it would always show the value for a specific mode. This is demonstrated below using the slider to always reflect a value from the field transmitter.

Double click the slider object to access its properties. Modify the Slider to use the new Tank_1_Level tag, then extend the tag to use the field value. This will force the slider to always use the real field value (as if it were a real field transmitter), regardless of the tag's mode.



Let's add a numerical input to allow us to set the override value when you are in override mode.




Select the Number object from the Toolbar and click to place it on the screen near the tank. Adjust the font, size, color and 3D shadowing to suit your style preferences.


Select the Display Value tab on the far right hand side of the form and enter the Numeric Expression: Tank_1_Level.field.v

Select Keyboard Commands under the Input tab, and Add a new key sequence: ##### Enter, with a command of Tank_1_Level.field.v = Arg1

Click OK when you are finished.




Copy and paste your new numerical input object, then double click it to access the new object's properties. Modify the Numeric expression to display: Tank_1_Level.Override.v, and the Input command to write to Tank_1_Level.Override.v = Arg1.



Click OK when you are finished.




If you want to, you can add static text beside each value to identify which is which, and a bounding box to group them together on the screen.




Save your page, then compile and run your project.


You should be able to change the field transmitter's value by using either the slider, or hovering over the field numeric value and typing in a new value on the keyboard. You will notice that the Override value is not updated.



From the Pages menu, select the Variable Tags page. You can resize the columns using the Autosize button at the top right of the page.




Locate the Tank_1_Level tag and right click on it, then change it to Override Mode.





You will notice that the value displayed has changed to zero. You can right click on the tag again and set a new override value. If you navigate back to your graphics page you will see that your display has changed due to the override mode.



Firstly, the bar graph has been dotted out, indicating that the value it is displaying is coming from the Override value, not the field transmitter. If you use the slider to modify the field value, you will see that the bar graph ignores it, and continues to use the override value at all times.

Secondly, the numeric value for the Override value and the Field value are displaying their respective values.


Finally, if you navigate to the Manual Override page, the tag will be listed here to allow you to easily identify any tags whose mode has been manipulated.

TIP There are numerous other features available for Tag Data Quality. Refer to the online help for more details, or experiment with the ManualOverride and Control Inhibit functions and pages available in your tutorial project.




6.2. Control Inhibit

Return to the Variable Tags page, and select the Pump_1_Speed tag. Right click and inhibit control of this tag.



Return to your graphics page and try to manipulate your pump's speed. As soon as you modify the value, it will return to the original value because the system is inhibiting any control of its value.

Similar to the tank level bar graph, the pump bar graph, slider and numerical display are dithered to indicate that the tag is not in its normal operating mode.



You can return to the Control Inhibit page and right click on the tag again to return it to its normal mode.

This completes the tutorial. We encourage you to attend a training course to learn more about the power of the Vijeo Citect product and how to make the most of its capabilities.